

Gewindestifte Innensechskant, Spitze ISO 4027

45H blank

Größe	Steigung	Innensechskant	Längen
M3	0,5		3, 4, 5, 6, 8, 10, 12
M4	0,7		4, 5, 6, 8, 10, 12, 14, 16, 20
M5	0,8		5, 6, 8, 10, 12, 16, 20
M6	1		6, 8, 10, 12, 16, 20, 25, 30, 35, 40, 50, 55
M8	1,25	4	8, 10, 12, 16, 18, 20, 25, 30, 35, 40
M10	1,5	5	10, 12, 16, 20, 25, 30, 35, 40, 45, 50
M12	1,75	6	10, 12, 16, 20, 25, 30, 35, 40, 45, 50, 55, 60
M16	2	8	16, 20, 25, 30, 35, 40, 45, 50, 60, 70, 80, 90
M20	2,5	10	30, 35, 40, 45, 50, 60

Maße in mm. Nennmaße; die Toleranzen stehen in der Norm.