

Gewindestifte Innensechskant, Spitze ISO 4027

Edelstahl A2

Größe	Steigung	Innensechskant	Längen
M2	0,4	0,9	3, 4, 5, 6, 8, 10
M3	0,5		3, 4, 5, 6, 8, 10, 12
M4	0,7		4, 5, 6, 8, 10, 12, 16
M5	0,8	2,5	5, 6, 8, 10, 12, 16, 20, 25
M6	1	3	5, 6, 8, 10, 12, 16, 20, 25, 30
M8	1,25	4	8, 10, 12, 16, 20, 25, 30, 35, 40
M10	1,5	5	10, 12, 16, 20, 25, 30, 35, 40, 45, 50
M12	1,75	6	12, 16, 20, 25, 30, 35, 40, 45, 50, 60, 70
M16	2	8	16, 20, 25, 30, 35, 40, 45, 50, 55

Maße in mm. Nennmaße; die Toleranzen stehen in der Norm.