

HELICOIL® Plus installation mandrels with depth stop

types: B-S 824 | E-S 410 | P-S 412 | P-S 1216

Type 4160.23 installation mandrel with depth stop to process HELICOIL® Plus Free Running coil thread inserts with UNF thread.



Suited for:

- B-S 206 cordless installation tool
- E-S 206 and E-S 410 electrical installation tools
- P-S 412 pneumatic installation tool

Properties:

- With external hexagon as per DIN 3126 – E 6.3/DIN ISO 1173

Note:

These installation mandrels can also be used as manual installation mandrels.

HELICOIL® Plus Screwlock installation mandrels are marked with a ring groove on the guide shaft. HELICOIL® Plus Free Running installation mandrels have a smooth guide shaft.

Technical information can be found on the last page.

Diameter (d)	Article number	Pitch (P)	Nominal length t ₂	Design
UNF 4-48	41602365720	0.53	7.1	HELICOIL® Plus Free Running
UNF 6-40	41602367720	0.63	7.0	HELICOIL® Plus Free Running
UNF 8-36	41602368720	0.71	4.2	HELICOIL® Plus Free Running
UNF 10-32	41602369720	0.79	4.8	HELICOIL® Plus Free Running

All technical data refer to the measure mm



HELICOIL® Plus thread inserts



W and d_1 are the control values for thread inserts (Free Running and Screwlock) before they have been installed. The length can only be measured for installed thread inserts.

Holding thread



Assembly



Prior to tapping, counter-bore 90° and deburr.
Outside diameter of **countersink** = $D_{HC} + 0.1 \text{ mm}$.

- | | |
|---|--|
| d = Nominal thread diameter | t_1 = Minimum depth of tapped hole according to DIN 76 – Part 1 (guide value) |
| P = Thread pitch | t_2 = The nominal length of the thread insert corresponds to the minimum length of the full parent thread for blind holes or the minimum plate thickness for a through hole. |
| d_1 = Outside diameter of thread insert prior to installation | t_3 = Maximum screw-in depth when the tang is not removed |
| W = Number of threads prior to installation | t_5 = Distance of the thread insert from the joint face = 0.25 to 0.5 P, if t_2 corresponds to the above-mentioned minimum value |
| D_{HC} = Outside diameter of the parent thread | |
| D_{1HC} = Crest diameter | |
| B = Suitable twist drill diameter. Please note: D_{1HC} is critical for selecting the correct twist drill diameter. | |

When you use HELICOIL® Plus thread inserts for volume production, we recommend to add at least $1 \times P$ to values t_1 and t_2 .